



Extrusion Head DSD

Compatible with:

■ HYDRA Floor Model ■ HYDRA Bench Model ■ System 30M ■ Engine ■ Engine HD



CONTENTS:

Specifications 2

Theory of Operation 3

Using the DSD 4

Tips 5

Warnings 5

Exploded View 6

B.O.M. 7

Crosslinking G-code 8

Crosslinking Schematic 9



Extrusion Head DSD

Compatible with:

■ HYDRA Floor Model ■ HYDRA Bench Model ■ System 30M ■ Engine ■ Engine HD

Specifications:

Programmable start/stop dwell in milliseconds

Programmable prime/unprime in nanoliters

Weight: 600 grams, plus payload

Material Capacity: 30cc

Power supply: 12v 2 amps max

Interface: CanBus or TTL

Stepping motor belt drive with reduction

Linear bearing rail



Precision ground drive screw

Plunger holder

Smart controller

Material syringe

Syringe holder





Theory of Operation:

The SDS series of extruders is designed to allow emulsified, low viscosity materials to be dispensed (printed), in a controlled way. The number of actual possible materials is vast, but we will list a few of our favorite materials to give you an idea: RTV Silicone clear, High Temp RTV, bio gels, epoxy, water....

While it is possible to print with food products, we do NOT recommend it, due to the difficulty of insuring sanitary conditions.

The SDS series of extruder heads all have smart controllers, and up to four heads can be loaded in a Hyrel printer at a time. This allows mixing of materials, or parallel printing of high volume small parts.

The syringe is loaded with the desired material, taking care not to get air inside the cylinder. The cylinder is loaded into the syringe clamp, loading the syringe plunger handle into the drive cradle. If you need to move the cradle, use the manual override switch, located at the top of the head controller, above the blinking leds.

The drive motor will turn at the desired rate when printing. The drive speed is controlled by head settings and the actual linear velocity of the print head, as set by the F argument in the G1, G2 or G3 commands. Generally speaking, you can print with the same code that you print plastic with, as long as the temperature and speed are set appropriately and the nozzle diameter is the same.



Using the DSD:

It is good to use RTV, (from your local hardware store), to learn with. Vaseline is also easy to use, but it will not get firm after printing.

Basically:

1. Load your material into the syringes
2. Mount the SDS head on your printer yoke,
3. Check the Z at the end of the needle on the syringe.
4. Load your G-Code file.
5. Print

We do NOT recommend printing food with the SDS. Just because it can be done does not mean that it should be done.

Once the head is installed, the syringes can be changed without removing the head from the yoke. If you use care, this will make it fast and easy to swap out materials.

You can use the M0 code to insert cylinder change stops (pauses) in your program.

Example:

```
G0 X0 Y200 ; move to material change location
M0 ; Install new material then press continue
```

Additional Help:

Check our YouTube channel and look for key words "Hyrel", "3DS", "Syringe", and "Silicone", for helpful videos.



Tips:

Use fresh syringes and tips to avoid contamination.

NO AIR should be inside the SDS Print Head. Pack your syringes carefully; it will make the material delivery spongy, and a crisp start and stop will be impossible.

NEVER put flammable material, such as gasoline, in your syringes.

ALWAYS USE good ventilation when using the syringes. Many of the more interesting materials will emit toxic fumes.

Maintenance:

Keep your SDS head clean. Do not allow material to get on the linear bearing or drive screw.

Use care when Installing the head into the yoke. Due to its long format, it is possible to mis-align the connection point.

Disclaimer:

!!! Use at your own risk. !!!

No warranty or guarantee is offered for the application of this product. The user agrees to be ENTIRELY responsible for the safe operation of this product.




Extrusion Head DSD

Compatible with:

■ HYDRA Floor Model ■ HYDRA Bench Model ■ System 30M ■ Engine ■ Engine HD

DSD Exploded View





Extrusion Head DSD

Compatible with:

■ HYDRA Floor Model ■ HYDRA Bench Model ■ System 30M ■ Engine ■ Engine HD

DSD BOM

Item	Qty	Part #	Part Name
1	1	102123	102123.TimingPulley.MXL-12.Modified
2	1	102160-M	102160-M.MXL36TX.710LONG-CUSTOM (Modified)
3	1	102187-2P-50	102187-2P-50C DSD Mounting Block 50cc (Bayonet style, Chi
4	1	102224-2P-50	102224-2P-50 2-Part Syringe EMO Bearing Block 50cc.v3
5	1	102239	102239 Syringe EMO Fixed Motor Mount.v4
6	1	102408-2SDS	102408-2SDS.Bearingrail.Extrusion.modified.for.SDS
7	1	102508	102508.PCBSpacerStop.H3D
8	1	102630	102630 dual epoxy syringe.v2
9	1	102637	102637 2-part epoxy syringe plunger
10	2	200016	200016_Bearing .25B X .625D X .205T R4F
11	1	200027-70	200027-70_Belt 125x70
12	10	200045	200045.M3.FlatWasher.93475A210
13	2	200080-3	200080-3.Nut,Hex,Star,M3
14	2	200086-25	200086-25.Screw,M3x25mmFlat
15	2	200088	200088.Nut,Hex,M3
16	4	200091-10	200091-10.M2.5x10.Socket.91292A014.
17	1	200094-1	200094-1 Precision Threaded Rod, 1mm pitch
18	1	200101-10	200101-10.M3x10.Hex.Standoff.FF.Brass
19	5	200303-10	200303-10.M3x10.SocketHead.Screw.SS.91292A113
20	4	200303-25	200303-25.M3X25.SOCKETCAP.91292A020
21	1	300310	300310.Motor.Stepping.0.8A.28x28x32mm
22	1	500207-3	500207.Extrusion Head Circuit Board

Syringe Suppliers

HYREL www.hyrel3d.com

McMaster Carr

Use the following syringes from BD Inc. for SDS, CSD, HSD, and CMS heads:

5cc 309646

10cc 309604

30cc 302832

60cc 309653



Photoinitiated Crosslinking: the SDS (Syringe Dispensing System) becomes the CSD (Crosslinking Syringe Dispenser).

The M106 command, used to control the fan which cools deposited material on the MK-series heads, controls the UV LED array on crosslinking heads. This functionality is the same on all CSD heads, as well as the COD, VCD, and KCD heads.

M106 T# S0 ; sets the COD LEDs (or fan) to 0% (off)

M106 T# S25 ; sets the COD LEDs (or fan) to 25%

M106 T# S100 ; sets the COD LEDs (or fan) to 100%

Note: T#, where # can be any of the following:

10 for yoke 1, ALL heads; or

11 for yoke 1, head 1; or

12 for yoke 1, head 2; or

13 for yoke 1, head 3; or

14 for yoke 1, head 4; or

15 for yoke 1, head 5; or

Left blank, to address the “currently active” head.



Extrusion Head DSD

Compatible with:

■ HYDRA Floor Model ■ HYDRA Bench Model ■ System 30M ■ Engine ■ Engine HD

